# 

## **S5 SERIES INSTRUCTION MANUAL**

### CONTROLS

OUTPUT LED The red LED indicates the output status.

STABILITY LED (S5-5-x)

The green LED ON indicates that the received signal has a reserve greater than 30% compared to the output switching value.

TRIMMER (S5-x-B3/C30/C35/C60/D14/E1/F8/F12) The trimmer can be used to adjust sensitivity; the operating distance increases turning the trimmer clockwise.

WARNING: The trimmer rotation is limited to 270° by a mechanical stop. Do not apply excessive torque when adjusting (max 40 Nmm).

#### POWER ON LED (S5-x-G8/G12)

The red LED indicates that the sensor is operating.


| CONNECTIONS          |            |              |                       |          |           |  |  |
|----------------------|------------|--------------|-----------------------|----------|-----------|--|--|
| S5-5-x (4 wires)     |            |              | S5-5-G8/G12 (4 wires) |          |           |  |  |
| BROWN 1              | +<br>LIGHT | DARK         | BROWN                 | <b>+</b> | 10 30 Vdc |  |  |
| 10 30 Vdc            | MODE       | MODE         | WHITE                 | 2        | TEST +    |  |  |
| WHITE 2<br>150mA NPN | WHITE      | 2<br>mA +    | BLACK                 | 4        | TEST -    |  |  |
| BLACK 4              | BLACK      | <b>4</b> PNP | BLUE                  | <u>-</u> | 0 V       |  |  |
|                      |            |              |                       |          |           |  |  |



| S5-5-x (3 wires) |                  |       |                     |  |  |  |  |
|------------------|------------------|-------|---------------------|--|--|--|--|
| BROWN            | 1<br>• 10 30 Vdc | BROWN | 1<br>1030 Vdc       |  |  |  |  |
| BLACK            | 4 LOAD 150mA     | BLACK | 4                   |  |  |  |  |
| BLUE             | 3<br>● 0 V       | BLUE  | 3 PNP<br>LOAD 150mA |  |  |  |  |

M12 CONNECTOR





|   | S5   | -5-x  | S5-1-x  |   |  |  |
|---|--|---|---|---|--|--|
|   | AXIAL VERSION  | RADIAL VERSION  | AXIAL VERSION                                   | RADIAL VERSION  |  |  |
| Power supply:                                     | 10 30 Vd   | 10 30 Vdc limit values  |   | 15 264 Vac (48 62 Hz) limit values                    |  |  |
| Ripple:   | 2 Vp   | 2 Vpp max.  |   | -   |  |  |
| Current consumption<br>(output current excluded): | 30 m/  | 30 mA max.  |   | 10 mA max.  |  |  |
| Output:   | NPN/PNP selectable; 30 Vdc max.<br>(short-circuit protection at 200 mA)  |   | SCR + bridge rectifier – 264 Vac                |   |  |  |
| Output current:                                   |  | 150 mA max.   |   | 100 mA max.   |  |  |
| Output saturation voltage:                        |  | 2.5 V max. / 1.2  | V max. mod. L2                                  |   |  |  |
| Rated insulation voltage:                         |  | -   | 250 Vac (test 1500 Vac 1 minutes)               |   |  |  |
| Output leakage:                                   | 50µA at 30 Vdc   |   | 1mA max. at 264 Vac                             |   |  |  |
| Response time:                                    | 1 ms max.<br>2 ms max. mod. F8/F12/G8/G12<br>6 ms max. mod. L2   |   | 20 ms max.                                      |   |  |  |
| Switching frequency:                              | 500 Hz max.<br>250 Hz max. mod. F8/F12/G8/G12<br>175 Hz max. mod. L2   |   | 25 Hz max.                                      |   |  |  |
| Indicators:                                       | OUTPUT LED (RED) / STABILITY LED (GREEN) / POWER ON LED (RED) mod. G8/G12  |   |   |   |  |  |
| Setting:  | sensitivity trimmer mod. B3/C30/C35/C60/D14/E1/F8/F12  |   |   |   |  |  |
| Operating temperature:                            | -25 55 °C  |   |   |   |  |  |
| Storage temperature:                              |  | -25   | 70 °C   |   |  |  |
| Electric shock protection:                        |  | Class 2   |   | Class 1   |  |  |
| Operating distance<br>(minimum):                  | A4: 0.1 4 m on R2<br>B3: 0.1 3 m on R2<br>C10: 1 10 cm<br>C35: 1 35 cm<br>D14: 10 20 mm<br>D15: 10 20 mm<br>F12/G12: 0 12 m<br>T1: 0.1 0.8 m on R2<br>E1 (0F-18): 22 mm<br>E1 (0F-19): 85 mm | A4: 0.1 4 m on R2<br>B3: 0.1 3 m on R2<br>C10: 1 10 cm<br>C35: 1 35 cm<br>C60: 1 60 cm<br>D15: 10 20 mm | C8: 1<br>C30: 1<br>D14: 10<br>D15: 10<br>F8/G8: | 2 m on R2<br>8 cm<br>30 cm<br>20 mm<br>20 mm<br>0 8 m |  |  |
| Emission type:                                    | INFRARED (880 nm) / RED (660 nm) mod. B3/D14/E1  |   |   |   |  |  |
| Ambient light rejection:                          |  |   | EN 60947-5-2                                    |   |  |  |
| Vibration:  | 0.5 mm amplitude, 10 55 Hz frequency, for every axis (EN60068-2-6)   |   |   |   |  |  |
| Shock resistance:                                 | 11 ms (30 G) 6 shock for every axis (EN60068-2-27)   |   |   |   |  |  |
| LIGHT/DARK selection:                             | by inverting the power supply wires (4 wires versions)   |   |   |   |  |  |
| Housing:  | ABS UL 94V-O   |   |   |   |  |  |
| Connector:  | Polyca   | rbonate   | ABS UL 94V-O                                    |   |  |  |
| Lenses:   |  |   | plastic   |   |  |  |
| Protection class:                                 | IP67   |   |   |   |  |  |
| Connections:                                      | 2 m cable Ø 5 mm / M12 4-pole connector  |   |   |   |  |  |
| Weight:   | 100 g. max. cable versions / 25 g. max. connector versions   |   |   |   |  |  |

#### SETTING

The following procedures are valid for LIGHT mode operation.

#### Alignment S5-x-A2/A4/B3/T1

Position the sensor and reflector on opposite sides.

Find the points where the red LED (OUT) is switched ON and OFF in both vertical and horizontal positions, and fix the sensor in the centre between these points

B/T models: Turn the sensitivity trimmer to maximum; if necessary reduce sensitivity in order to detect very small or transparent targets. In order to improve alignment, repeat the procedure detailed above whilst progressively reducing the sensitivity.

#### Alignment S5-x-F8/G8/F12/G12/E1 (E/R fibres)

Position the sensors on opposite sides.

Turn the sensitivity trimmer to maximum. Find the points where the red LED (OUT) is switched ON and OFF in both vertical and horizontal positions, and fix the sensor in the centre between these points. Optimum operation is obtained when both LEDs switch ON. If necessary, reduce sensitivity using the trimmer, in order to detect very small targets. In order to improve alignment, repeat the procedure detailed above whilst progressively reducing the sensitivity.

#### Alignment S5-x-C30/C35/C60/D14/E1 (proximity fibres)

Position the sensor and turn the sensitivity trimmer at minimum: the green LED is ON and the red LED is OFF. Place the target opposite the sensor. Turn the sensitivity trimmer clockwise until the red LED turns мах ON (Target detected state, pos.A).

Remove the target, the red LED turns OFF. Turn the trimmer clockwise until the red LED turns ON (Background detected state, pos.B). The trimmer reaches maximum if the background is not detected. Turn the trimmer to the intermediate position C, between the two positions A and B. The green LED must be ON.

)†<sup>B</sup>

#### Alignment S5-x-C8/C10/D15/L2

The operating distance range of these sensors is factory preset: please consider this feature when positioning.

### **TEST FUNCTION (S5-x-G8/G12)**

The TEST+ and TEST- inputs can be used to inhibit the emitter and verify that the system is correctly operating.

The receiver output should switch when the test is activated while the beam is uninterrupted.

The inputs activating voltage range is 10 ... 30 Vdc, whilst respecting the polarity.

#### DECLARATION OF CONFORMITY

We DATALOGIC AUTOMATION declare under our sole responsibility that these products are conform to the 2004/108/CE and successive amendments. E

#### WARRANTY

DATALOGIC AUTOMATION warrants its products to be free from defects.

DATALOGIC AUTOMATION will repair or replace, free of charge, any product found to be defective during the warranty period of 36 months from the manufacturing date.

This warranty does not cover damage or liability deriving from the improper application of DATALOGIC AUTOMATION products.

#### DATALOGIC AUTOMATION

Via Lavino 265 - 40050 Monte S.Pietro - Bologna - Italy Tel: +39 051 6765611 - Fax: +39 051 6759324 www.automation.datalogic.com e-mail:info.automation@datalogic.com

DATALOGIC AUTOMATION cares for the environment: 100% recycled paper. DATALOGIC AUTOMATION reserves the right to make modifications and improvements without prior notification.

Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A. in many countries, including the U.S.A. and the E.U.

826000177 Rev.G

© Copyright Datalogic 2007-2009