
# **Safety Technique**

# SAFEMASTER M Multi-Function Safety System Input Module


BG 5913.08/\_0\_ \_\_, BH 5913.08/\_0\_ \_\_



## **Block Diagram**







## BH 5913

- According to
  Performance Le
  - Performance Level (PL) e and category 4 to EN ISO 13849-1: 2008
    SIL Claimed Level (SIL CL) 3 to IEC/EN 62061

- Safety Integrity Level (SIL 3) to IEC/EN 61508
- Category 4 to EN 954-1
- Input module for realization of
  - 4 similar 2-channel inputs
  - Emergency stop circuits
- Safety gate monitoring system
- Two-hand control type IIIA, IIIC acc. to DIN/EN 574
- Light curtain (LC type 4)
- · The functions are selected via rotary switch
- 8 safety inputs
- 2 semiconductor outputs for status indication
- Broken wire and short circuit monitoring function with error indication
- · LEDs for status indication
- Width

BG 5913.08/\_0\_ \_ \_: 22.5 mm BH 5913.08/\_0\_ \_: 45 mm

# **Approvals and Marking**



<sup>1)</sup> The approval to EN 954 will be replaced by a TÜV-approval according to EN ISO 13849-1:2008, IEC/EN 62061, e. g. 61508


# Applications

Realization of fail-safe control circuits for protection of people and machinery.


Note: This module is intended for applications in which mixed safety functions affect one common output.

 $\label{eq:second} \begin{array}{l} \mbox{Further input modules with other combinations of functions are provided} \\ (e.g. BG 5913.08/_1 \_ _ , BG 5913.08/_2 \_ _ , BG 5913.08/_3 \_ _ , BG 5914.08/_0 \_ _ , BH 5914.08/_0 \_ _ or BG 5914.08/_1 \_ _). \end{array}$ 

# **Circuit Diagrams**



BG 5913



## BH 5913

# **General Information SAFEMASTER M**

The maximum configuration of the SAFEMASTER M multi-function safety system is as follows:

- the control unit BH 5911
- up to 3 input modules BG 5913, or BG/BH 5914, BG/BH 5915
- up to 3 output modules BG 5912
- 1 diagnostic module BG 5551 for CANopen, or
- 1 diagnostic module BG 5552 for Profibus-DP

The BH 5911 controls the whole system.

The input/output modules can be used to expand the control unit in a modular way into a multi-functional safety system.

To transmit status messages of the individual modules to a monitoring or control unit, one of the following diagnostic modules may be connected:

- BG 5551 for CANopen
- BH 5552 for Profibus-DP

# Notes

In respect of function and settings, the modules BG 5913 and BH 5913 are completely identical.

- The modules BG 5913 have 8 inputs with one common ground. This is the ground of the overall system. They are suitable for all applications in which volt free contacts are used, or where there is a common ground (e.g. 2-channel light curtains). They need only 8 terminals and thus only have an overall width of 22.5 mm.
- The modules BH 5913 have 8 completely DC-decoupled inputs. This allows with setting 1 and 3 (4 lightcurtains) to connect also 4 two-channel e-stop buttons with long connection wires with static signal potental. Here, short-circuit monitoring is effected by a certain type of wiring according to the application examples.


#### Indication


Green LEDs:	on, when all inputs are present and start button activated.
White LEDs Run1/	
Run 2 and outputs	
48 and 58:	indicate the current status of the module.

#### Setting of the Module

The module is assigned to the start inputs and the safety outputs via the DIP switches.

The combinations of individual functions are set via the rotary switches. To prevent accidently adjustments, these elements are covered by a front plate and are redundant.





# Note:

 Settings to the unit must be performed by skilled personnel while the unit is disconnected.

• Before the front cover is removed, antistatic precautions must be observed.

## Setting of the Modules

Sw.	Function
0	4 Emergency stop 2-channel, autostart
1	4 light curtains category 4, autostart
2	4 Emergency stop 2-channel, manual start
3	4 light curtains category 4, manual start
4	4 safety gates with 2 single contacts
5	2 safety gates with 2 changeover contacts
6	1 safety gate with 2 twin contacts and 1 single contact,
0	manual start (plastic injection moulding machines) to EN 201
7	1 safety gate with 3 twin contacts, manual start
	(plastic injection moulding machines) to EN 201
8	4* two-hand control IIIA acc. to EN 574
9	2* two-hand control IIIC acc. to EN 574

When using setting 8 or 9 the user has to indicate clearly on the device which type of 2-hand function is adjusted (IIIA or IIIC).

## Automatic Start

Automatic start is performed only when supply voltage is switched on, or when the emergency stop or stop function has been reset. All other errors nevertheless require confirmation by a start input.

#### **Manual Start**

To start the system, do not keep the start key pressed for more than 3 seconds. A module may also be assigned several start keys.

## **One-Channel Input**

With setting 6), it is imperative to use a voltfree contact for the single contact. A static signal cannot be used.

## Simulation Input for Function of Safety Gates

When the unit is set to monitor safety gates according to EN 201 switch position 4, 5, 6 and 7, closing of the assigned safety outputs is only enabled, if every gate has changed from open state (all contacts inactive) to closed state within a maximum period of 3 sec on each gate.

When the system is powered up with some gates open and some closed the open gates can be closed and the system can be started up by the simulation button, simulating an open-close cycle of the previously closed gates.

Only those gates are simulated, that had been closed before the system was powered up.

Simulation is only possible once after the unit is powererd up. After that all contacts of a gate have to be opened and reclosed to enable the outputs again. When closing the gate all contacts of a gate have to close within 3 sec.

## Function of the Two-Hand Control

Up to 4 pairs of two-hand safety circuits can be connected with the twohand safety function. However, no more than one circuit may be activated. To permit enabling of the assigned safety outputs, the following conditions must be fulfilled:

- 1) First, none of the connected two-hands circuits must be activated.
- 2) Both buttons of a two-hand control must be pressed within 0.5 s.
- When changeover contacts (type IIIC acc. to DIN / EN 574) are used for the two-hand-safety buttons, they must effect changeover of contacts within 50 ms.
- As soon as a button of a second two-hand circuit is pressed, the outputs are disabled, and condition 1) must be fulfilled once more before a new enabling cycle can start.
- 5) The two-hand buttons habve to be released if an other function module, also assigned to the same outputs disables the outputs.
- Only one two-hand control module is allowed in one safemaster M system.

The unit must be connected as specified in the application examples. When the operating contacts are connected in parallel or in series, safe functioning of the unit is cancelled.

The two-hand buttons must be designed and arranged in such a way as to ensure that they cannot be disabled easily, or pressed unintentionally.

The safety distance between the push buttons and the place of danger must be large enough to insure that after releasing a button, the place of danger can only be reached after the dangerous movement has stopped. The safety distance "S" is calculated according to the following formula:

#### **Function of the Two-Hand Control**

 $S = V \times T + C$ , where

- a) gripping velocity V = 1 600 mm/s
- b) overtravel time T (s)
- c) and safety factor C = 250 mm.

When any access into the dangerous area, with operating keys pressed, is safely prevented, e.g. by a protective cover for the keys, the safety factor C may be set to the value 0. Generally, the minimum safety distance must be 100 mm. See also DIN/EN 574.

## Safety Gate Function

The safety gate function always permits enabling if both contacts change from inactive to active state within 3 seconds. If the second contact reacts later, both changeover contacts must turn inactive before they can be enabled again.

When activating the system, press the start button to simulate the compulsory opening and re-closing of safety gates which have been kept closed since the system has started.

This simulation is possible only before enabling has been permitted for the first time, and as long as both safety gate contacts remain closed as well. As soon as a contact opens, simulation of the safety gate function is no longer possible.

# E-Stop or Light Curtain (LC) Function

In the Emergency stop or LC functions, both signals have to change from inactive state into active state within 250 ms. If the second signal reacts later, both changeover contacts must turn inactive before they can be enabled again.

With manual start, all safety inputs must be active before the start button can be pressed to trigger enabling. To start the system, do not keep the start button pressed for more than 3 seconds. A module may also be assigned several start buttons.

Note: Connect only self-testing light curtains of the type 4 acc. to EN 61496 to the module. Short-circuit monitoring of the inputs for the LC must be done in the LC.

## Indication of System Errors:

These errors are indicated by flashing codes of the white LEDs Run 1 and/or Run 2. The green LEDs and all outputs turn inactive. The system will only restart after the supply voltage has been switched off and on again.

## Error codes\*

- 0) (both white LEDs are off):
- Another input module indicates a system error. 1) To 4): not used
- 5) Incorrect setting of function:
  - The rotary switches for channel 1 and 2 has different or incorrect positions
  - The setting of the 4 upper Dip-switches (channel 1) are not identically to the 4 lower Dip-switches (channel 2)
- 6) LED Run 1 flashes: Undervoltage LED Run 2 flashes: Overvoltage
- 7), 8) Not used
- 9) Connection error between the input modules No terminating connector available. Control or input module defective
- 10), 11), 12), 13) a. 14) Internal errors

\* number of short flashing impulses, followed by a longer space

Indication			
	Permanently OFF	Pulsing	Permanent ON
Output 48	all relays inactive due to system error	one input function not available	Activation of the assigned safety outputs is permissible
LED Run 1	Two-hand control not activated (LED run 2 ON) or all relays inac- tive due to system error	one input function not available (LED run 2 ON) or system error when LED Run 2 is OFF or flashing	Activation of the assigned safety outputs is permissible
Output 58	Activation of the assigned safety outputs is permis- sible or system error	Error exists no more, waiting for Start input	one input function not available
LED Run 2	all relays inactive due to system error	all relays inactive due to system error	No system error

# **Function Error Indication**

Function errors are indicated by the white LED Run 1 and by output 48; the white LED Run 2 remains on. Output 58 is ON as long as the error is pending; it flashes regularly, while waiting for the assigned start signal.

# Error codes\*


- Normal interruption of function (e.g. Emergency stop) 1)
- 2) Time error: (e.g. the second two-hand button is not pressed)
- With gate monitoring: simulation input error (kept pressed for 3)
- too long) 4) Error at start input
- 5) Input error (short-circuit, interruption)
- 6) Error in the control unit (input or output error detected in the control unit)


\* number of short flashing impulses, followed by a longer space

# Special with two-hand control:


When both two-hand buttons of the module are inactive while all other functions are active and enabled either by autostart or via the start button, output 48 and the white LED Run 1 are permanently OFF, and output 58 permanently ON.


# **Function Diagramms**





Emergency stop or light curtain, automatic start







Emergency stop or light curtain, manual start

Safety gates (example: 4 gates with 2 single contacts each), assigned start buttons are also suitable for gate simulation (setting 4 or 5)


# **Function Diagramms**




Safety gate for plastic moulding machines (example: 1 gate with double contacts + single contact) (setting 6 or 7)



Two-hand control




4 Emergency stop circuits, 2-channel, auto/manual start with short circuit monitoring; function: 0, 2




4 Emergency stop circuits, 2-channel, auto/manual start, short circuit monitoring by wiring; function 1, 3

# **Application Examples**




4 light curtains, category 4, auto/manual start; function: 1,3




4 safety gates with 2 NO contacts; function: 4


# **Application Examples**




2 safety gates with 2 antivalent changeover contacts each; function: 5



1 safety gate with 2 twin/1 single contact, manual start (plastic injection moulding machines); function: 6




1 safete gate with 3 twin contacts, manual start (plastic injection moulding machines); function: 7



4 two-hand controls type IIIA acc. to DIN/EN 574; function: 8

# **Application Examples**



2 two-hand controls type IIIC acc. to DIN/EN 574; function: 9

BH5911)

max. 60mA

internally with PTC

4.5 mA each at U<sub>N</sub>

DC 24 V (coming from the basic module

(no load on semiconductor outputs)

Technical	Data
reorniour	Dutu

# Voltage Supply

Voltage range: with max. 5% residual ripple: 0.85 ... 1.15  $U_N$ Nominal consumption:

Short-circuit protection of the modules:

Input

**Control voltage** via X1, X2, 48.58:

DC 23 V at  $U_{\rm N}$ 

**Control voltage** via S12, S14, S22, S24, S32, S34, S42, S44:

Minimum voltage

on S12, S14, S22, S24, S32, S34, S42, S44:

# Semiconductor Outputs

Output at terminal 48 and 58: Transistor outputs, plus-connected DC 24 V, max. 100 mA constant current, Output nominal voltage: max. 400 mA for 0.5 s Internal short circuit, overtemperature, and overload protection

DC 16 V

#### Reaction Times (time till reaction of the assigned output):

# Typ. NO time with U<sub>N</sub>:

Input modules BG 5913	Manual start	Automa	tic start
		First start	Restart
Emergency stop	max. 80 ms	max. 1 s	max. 115 ms
Light barriers	max. 80 ms	max. 1 s	max. 115 ms
Safety gates	or simulation: max. 80 ms		Gate closing: max. 115 ms
Two-hand control	max. 85 ms		

# **Technical Data**

Break Time (reaction time):

Input modules BG 5913		
Emergency stop	max. 33 ms	
Light barriers	max. 33 ms	
Safety gates	max. 33 ms	
Two-hand control	max. 33 ms	

Continuous operation

a distance of 3 - 5 mm.

At an operating temperature of 50 °C

the modules must be mounted with

± 0 ...+ 50 °C

# **General Data**

**Operating mode:** Temperature range:

# Clearance and creepage

distances			
distances			
rated impuls voltage /			
pollution degree:	4 kV / 2 (basis insulation) IEC 60 664-1		
EMC	101/1		
HF irradiation:	10 V / m	IEC/EN 61 000-4-3	
Fast transients:			
on supply line A1-A2	2 kV	IEC/EN 61 000-4-4	
on signal and control lines:	2 kV	IEC/EN 61 000-4-4	
Surge voltages			
between			
wires for power supply:	1 kV	IEC/EN 61 000-4-5	
wire and ground:	2 kV	IEC/EN 61 000-4-5	
HF wire guided:	10 V	IEC/EN 61 000-4-6	
Radio interference			
suppression:	Limit value class B	EN 55 011	
Degree of protection			
Housing:	IP 20	IEC/EN 60 529	
Terminals:	IP 20	IEC/EN 60 529	
Housing:	Thermoplastic with V	0 behavior	
C C	according to UL Sub	ject 94	
Vibration resistance:	Amplitude 0.35 mm	, IEC/EN 60 068-2-6	
	Frequency 1055 H	Z,	
Shock resistance			
Acceleration:	10 g		
Pulse duration:	16 ms		
Number of shocks:	1000 per axis on thre	e axes	
Climate resistance:	0 / 050/ 04	IEC/EN 60 068-1	

0 / 050/ 04 IEC/EN 60 068-1 EN 50 005

Terminal designation:

#### **Technical Data**

Wire connection: Wire fixing:	1 x 2.5 mm <sup>2</sup> stranded wire with sleeve, or 1 x 4 mm <sup>2</sup> massive or 2 x 1.5 mm <sup>2</sup> stranded wire with sleeve DIN 46 228-1/-2/-3/-4 Box terminal with wire protection, remov- able terminal strips.	
Mounting: Weight:	on DIN rail	IEC/EN 60 715
BG 5913:	193 g	

255 g

BG 5913.08/00MF0	DC 24 V
Article number:	0055530
BH 5913.08/00MF0	DC 24 V
Article number:	0059242

Standard Type

#### Dimensions

BH 5913:

# Width x height x depth

ЪG	5915.
ΒH	5913:

22.5 x 84 x 121 mm 45 x 84 x 121 mm

## Safety Related Data for E-STOP

Values according to EN IS	O 13849-1:	
Category:	4	
PL:	е	
MTTF <sub>d</sub> :	812.8	а
DC <sub>avg</sub> :	96.0	%
d <sub>op</sub> :	365	d/a (days/year)
d <sub>op</sub> : h <sub>op</sub> : t	24	h/d (hours/day)
t:	3600	s/Zyklus
_,	≙ 1	/h (hour)

# Values according to IEC EN 62061 / IEC EN 61508:

SIL CL:	3	IEC EN 62061
SIL	3	IEC EN 61508
HFT <sup>*)</sup> :	1	
DC <sub>avg</sub> : SFF	96.0	%
SFF	99.2	%
PFH <sub>D</sub> :	2.34E-10	h⁻¹

# Safety Related Data for light curtains ,safety gates or two-hand

## Values according to EN ISO 13849-1:

Category:	4	
PL:	е	
MTTF <sub>d</sub> :	2697.1	а
DC <sub>avg</sub> :	96.0	%
d	220	d/a (days/year)
d <sub>op</sub> : h <sub>op</sub> :	12	h/d (hours/day)
t <sub>Zyklus</sub> :	138	s/Zyklus

# Values according to IEC/EN 62061 / IEC/EN 61508:

SIL CL:	3	IEC/EN 62061
SIL	3	IEC/EN 61508
HFT <sup>*)</sup> :	1	
DC <sub>avg</sub> : SFF	96.0	%
SFF	99.2	%
PFH <sub>D</sub> :	2.34E-10	h⁻¹

\*) HFT = Hardware-Failure Tolerance



The values stated above are valid for the standard type. Safety data for other variants are available on request. The safety relevant data of the complete system has to be

determined by the manufacturer of the system.

E. DOLD & SÖHNE KG • D-78114 Furtwangen • PO Box 1251 • Telephone (+49) 77 23 / 654 - 0 • Telefax (+49) 77 23 / 654 - 356